
Introduction to Photometry with HST

This is an unofficial document for internal RIAB training purposes only

*Roberto J. Avila
Space Telescope Science Institute
3700 San Martin Dr.
Baltimore, MD 21209
Version 1.0*

August 2012

Revision History

Version	Date	Editors and Contributors
1.0	August 2012	Roberto J. Avila

You will be using images of the globular cluster NGC6791 taken with ACS/WFC using two broadband filters. You will perform aperture photometry on these images and produce a color magnitude diagram of the cluster. Here is an outline of the procedure followed by a few explicit instructions on how to perform the tasks necessary to complete this exercise.

1. Convert your images from counts per second to counts and add sky that was removed by AstroDrizzle
2. Use one of your images to find stars and define a source catalog
3. Use catalog to perform aperture photometry on your images
4. Extract photometry information from daophot output files
5. Determine aperture corrections for each frame
6. Apply aperture corrections and produce final catalog in STMag
7. Make CMD of globular cluster in F606W-F814W vs F814W

1 Making a counts image

You will be using the DAOPHOT package within IRAF. The tasks in this package assume that the images you will be using are in counts and that the sky is part of the image. AstroDrizzle products are in counts/second and do not contain sky. We will modify our images so they comply with what DAOPHOT expects. To start navigate to the directory containing your ***drc_sci.fits** images and start Pyraf and then load the DAOPHOT package:

```
avila@avila: phot > pyraf
setting terminal type to xterm...
```

```
NOAO/IRAFNET PC-IRAF Revision 2.14 Fri Nov 30 15:27:05 MST 2007
This is the RELEASED version of IRAF V2.14 supporting PC systems.
```

```
Welcome to IRAF.  To list the available commands, type ? or ??.  To get
detailed information about a command, type `help <command>'.  To run a
command or load a package, type its name.  Type `bye' to exit a
package, or `logout' to get out of the CL.  Type `news' to find out
what is new in the version of the system you are using.
```

```
Visit http://iraf.net if you have questions or to report problems.
```

```
The following commands or packages are currently defined:
```

```
IIIII   RRRR   AAA   FFFFF   XX  XX
      I     R  R   A   A   F       X  X
```

```

      I      RRRR      AAAAA      FFF      XX
      I      R  R      A  A      F      X  X
      IIIII   R   R    A   A    F      XX  XX

```

IRAFX Prepared 2012-08-16

```

clpackage/:
  apropos      fitsutil/      mscred/      salt/      user/
  cirred       gemini/      nmisc/      softtools/  utilities/
  clpackage/   gmisc/      noao/      stecf/      wcstools/
  color/       images/     obsolete/   stlocal/   xdimsum/
  ctio/        iuertools/  plot/      stsdas/
  dataio/      language/   proto/     system/
  dbms/        lists/      rvsao/     tables/

```

PyRAF 2.1.dev Copyright (c) 2002 AURA

Python 2.7.1 Copyright (c) 2001-2010 Python Software Foundation.

Python/CL command line wrapper

.help describes executive commands

--> digiphot

digiphot/:

```

  apphot/      daophot/      photcal/      ptools/

```

--> daophot

daophot/:

```

  addstar      daotest      nstar      pexamine      psf
  allstar      datapars@   pcalc      pfmerge      psort
  centerpars@  findpars@   pconcat    phot          pstselect
  daoedit      fitskypars@ pconvert    photpars@    seepsf
  daofind      group       pdump      prenumber     setimpars
  daopars@     grpselect   peak       pselect      substar

```

-->

You will be using the PyFits package to manipulate your images so import that:

--> import pyfits

-->

The 0th extension of drizzled images contains your image header and science data. The first extension contains the header information from all the images you used to create your drizzled image. The header of the input images is contained in the form of a table. We need all this information so we will load it all to memory:

```

--> f = pyfits.open('f606w_drc_sci.fits') #open fits file
--> fdata = f[0].data      #reads 0th extension data into variable fdata
--> fheader = f[0].header  #reads 0th extension header into variable fheader
--> ftable= f[1].data      #reads 1st extension data into variable ftable

```

```
--> f.close()                #closes image
-->
```

Now let's look for some information we need, namely the total exposure time (`texptime`) in this image and how much sky was subtracted from each image (`mdrizsky`). Take note of the different syntax used to query headers and tables:

```
--> fheader['texptime']
7024.0
--> ftable.field('mdrizsky')
array([ 85.60038757,  85.60038757,  90.88925171,  90.88925171,
        97.06797791,  97.06797791,  91.16620636,  91.16620636,
        95.353508   ,  95.353508   ,  96.62722015,  96.62722015])
-->
```

Notice there are 12 values for `mdrizsky` even though there were only 6 images in your stack. This is a ‘feature’ of AstroDrizzle which tells you how much sky was subtracted from each chip in your stack. Anyway, sum up your values and divide by two to figure out the total amount of sky. Remember that when the sky was subtracted your images still had their original plate scale (0.05"/pix), but your drizzled images have smaller pixels. You need to rescale your sky to the new plate scale to ensure your total sky flux is conserved throughout the image. The formula to compute your final image looks like this:

$$f_{606cts} = f_{606cps} \times exptime + \frac{\sum mdrizsky}{2} \times rescale^2 \quad (1)$$

where $rescale = 0.03/0.05$. In the command line type

```
--> f606cts = fdata*7024. + 556.7*0.6*0.6    #See how easy things are with pyfits?
-->
```

Now write out your data to a FITS file, including the header, and you're done:

```
--> pyfits.writeto('f606w_cts.fits',f606cts,header=fheader)
-->
```

2 Defining a source catalog

Use the DAOFIND task to find stars in one of your images. First of all, make sure to run the “unlearn” command on DAOFIND to reset everything to the default values. After that change the following parameters and execute the task. Remember that some parameters are found by pushing the **PSET datapars** and **PSET findpars** buttons and that you must save the values in each window when you edit them:

- image = f606w_cts
- output = starlist

- $\text{fwhmpsf} =$ (measure the psf of a few stars in your image and use $2 \times$ that value)
- $\text{sigma} =$ (use `imexam` to determine the sky standard deviation in your image)
- $\text{readnoise} =$ (ACS `rdnoise` is $5.5e^-$, but that value needs to be rescaled to the plate scale of your image, see equation 2)
- $\text{itime} = 7024$.

The read-noise in each image is 5.2 electrons, but you need to rescale that to the new pixel size and take into account that there are 6 images in your stack. To figure out your new read-noise use this equation:

$$\text{new_rdnoise} = \sqrt{n\text{frames} \times (\text{old_rdnoise} \times \text{rescale})^2} \quad (2)$$

Finally use the PHOT task to perform aperture photometry. Your **PSET datapars** parameters should carry over from the FIND task but you need to edit other settings:

- `image = f606w_cts`
- `coords = starlist`
- `output = f606w.raw`
- `calgorithm = centroid`
- `salgorithm = median`
- `annulus = 17`.
- `dannulus = 3`.
- `apertures = 5.,16.666`
- `zmag =` (the appropriate zeropoint for each filter)

This will run for some time but when it is finished you will have a file in your directory called **f606w.raw**.

3 Extract photometry from DAOPHOT files

All the photometry information you need is in this file which looks like this:

```
--> !more f606w.raw
#K IRAF      = NOAO/IRAFV2.14EXPORT    version    %-23s
#K USER      = avila                   name       %-23s
#K HOST       = Tac-OSX04.local         computer   %-23s
#K DATE       = 2012-08-20              yy-mm-dd  %-23s
#K TIME       = 20:15:05                hh:mm:ss  %-23s
#K PACKAGE    = apphot                  name       %-23s
#K TASK       = phot                    name       %-23s
```

#		
#K SCALE	= 1.	units %-23.7g
#K FWHMPsf	= 2.6	scaleunit %-23.7g
#K EMISSION	= yes	switch %-23b
#K DATAMIN	= INDEF	counts %-23.7g
#K DATAMAX	= 9000000.	counts %-23.7g
#K EXPOSURE	= ""	keyword %-23s
#K AIRMASS	= ""	keyword %-23s
#K FILTER	= ""	keyword %-23s
#K OBSTIME	= ""	keyword %-23s
#		
#K NOISE	= poisson	model %-23s
#K SIGMA	= 13.	counts %-23.7g
#K GAIN	= ""	keyword %-23s
#K EPADU	= 1.	e-/adu %-23.7g
#K CCDREAD	= ""	keyword %-23s
#K READNOISE	= 7.3	e- %-23.7g
#		
#K CALGORITHM	= centroid	algorithm %-23s
#K CBOXWIDTH	= 5.	scaleunit %-23.7g
#K CTHRESHOLD	= 0.	sigma %-23.7g
#K MINSNRATIO	= 1.	number %-23.7g
#K CMAXITER	= 10	number %-23d
#K MAXSHIFT	= 1.	scaleunit %-23.7g
#K CLEAN	= no	scaleunit %-23b
#K RCLEAN	= 1.	scaleunit %-23.7g
#K RCLIP	= 2.	scaleunit %-23.7g
#K KCLEAN	= 3.	sigma %-23.7g
#		
#K SALGORITHM	= median	algorithm %-23s
#K ANNULUS	= 10.	scaleunit %-23.7g
#K DANNULUS	= 3.	scaleunit %-23.7g
#K SKYVALUE	= 0.	counts %-23.7g
#K KHIST	= 3.	sigma %-23.7g
#K BINSIZE	= 0.1	sigma %-23.7g
#K SMOOTH	= no	switch %-23b
#K SMAXITER	= 10	number %-23d
#K SLOCLIP	= 0.	percent %-23.7g
#K SHICLIP	= 0.	percent %-23.7g
#K SNREJECT	= 50	number %-23d
#K SLOREJECT	= 3.	sigma %-23.7g
#K SHIREJECT	= 3.	sigma %-23.7g
#K RGROW	= 0.	scaleunit %-23.7g
#		
#K WEIGHTING	= constant	model %-23s
#K APERTURES	= 3.,10.,16.666	scaleunit %-23s

```

#K ZMAG          = 26.678                      zeropoint  %-23.7g
#
#N IMAGE          XINIT      YINIT      ID      COORDS          LID      \
#U imagename      pixels     pixels     ##      filename        ##      \
#F %-23s          %-10.3f    %-10.3f    %-6d    %-23s          %-6d
#
#N XCENTER        YCENTER    XSHIFT     YSHIFT    XERR      YERR          CIER CERROR  \
#U pixels         pixels     pixels     pixels    pixels    pixels      ##  cerrors  \
#F %-14.3f        %-11.3f    %-8.3f    %-8.3f    %-8.3f    %-15.3f      %-5d %-9s
#
#N MSKY           STDEV       SSKEW      NSKY     NSREJ      SIER SERROR  \
#U counts         counts      counts      npix     npix       ##  serrors  \
#F %-18.7g        %-15.7g     %-15.7g     %-7d     %-9d       %-5d %-9s
#
#N ITIME          XAIRMASS    IFILTER     OTIME          \
#U timeunit       number      name         timeunit       \
#F %-18.7g        %-15.7g     %-23s        %-23s
#
#N RAPERT         SUM         AREA         FLUX         MAG     MERR     PIER PERROR  \
#U scale          counts      pixels        counts        mag     mag     ##  perrors  \
#F %-12.2f        %-14.7g     %-11.7g     %-14.7g     %-7.3f  %-6.3f  %-5d %-9s
#
f606w_cts.fits    6505.001    269.006    1      starlist          1      \
6505.000    269.018    -0.001    0.012    0.001    0.001          0      NoError  \
200.4136    20.16031    18.36138    168     44          0      NoError  \
7024.        INDEF      INDEF          INDEF          \
3.00    1226540.    28.38765    1220851.    21.078 0.001 0      NoError *\
10.00    1353694.    314.7326    1290617.    21.017 0.001 0      NoError *\
16.67    1479307.    872.9724    1304351.    21.006 0.002 0      NoError *
f606w_cts.fits    6420.338    271.456    2      starlist          2      \
6420.557    271.464    0.219    0.008    0.021    0.014          0      NoError  \
200.4137    0.        0.        102     118          0      NoError  \
7024.        INDEF      INDEF          INDEF          \
3.00    10795.87    28.33908    5116.329    27.022 0.015 0      NoError *\
10.00    82445.52    314.1608    19483.4    25.570 0.008 0      NoError *\
16.67    223457.9    872.4777    48601.5    24.578 0.005 0      NoError *

```

As you can see this photometry file contains a lot of information about the image and photometry parameters. Following the comments you can see the photometry information for each of the stars. Unfortunately it is not in a format that is easy for programming/plotting tools to read. Have no fear, txdump is here to help. txdump is a task in IRAF that can read DAOPHOT files and extract the columns you ask for. Let's extract the star positions and magnitudes for now.

```
--> txdump f606w.raw xcenter,ycenter,mag yes > f606w.phot
```

It's that easy. If you look at the first 10 lines of your **f606w.phot** file it should look like this:


```
--> !head f606w.phot
6505.000 269.018 21.078 21.017 21.006
6420.557 271.464 27.022 25.570 24.578
6457.000 272.500 27.802 26.979 25.991
6391.617 272.543 25.965 22.090 21.233
6306.500 274.499 24.918 24.742 24.490
6360.782 274.000 26.480 25.557 24.722
6504.341 274.001 24.954 21.021 21.021
6272.000 275.500 26.713 26.339 25.661
6224.496 276.500 26.568 25.257 24.230
6328.593 276.500 26.484 26.239 25.968
-->
```

The first two columns are the x and y positions of the stars. The next three columns are the magnitudes of the stars in your three apertures. There will be some bad measurements (INDEF) in your file. Use your favorite text editor or sed to change any "INDEF" to "99.999".

4 Aperture corrections

Now that you have your data in a usable format, use your favorite plotting tool to display Δmag vs mag_{r3} . Your plot should look something like figure 1.




Figure 1: Aperture correction for F606W drizzled image.

Use the bright, unsaturated stars and your favorite estimator to find the value of the aperture correction (ac05) for this image. You can see where I've marked the aperture correction in my plot. Should the value of the aperture correction be negative or positive? When you apply the correction should it be added or subtracted?

For the encircled energy correction (AC05) look up the values in Table 5 of Sirianni et al (2005PASP..117.1049S).

You will need to repeat steps 1 – 5 for the F814W image.

Finally you will need to merge your two catalogs. The positions of your sources won't be exactly the same between the two catalogs so you will have to match the sources by position using some tool like tmatch or xyxymatch. Once you have your master catalog with all the stars and (corrected) magnitudes you can make your CMD.

Place your aperture correction plots and CMDs in your results folder so I can review your work.