

MIRI Detectors:


Using Reference Outputs and Reference Pixels

Version History:

2011: Rachel Anderson for RIAB Training

2009: Scott Friedman for JWST Detector Course

MIRI Field of View




Detector Characteristics

- ⊗ Ar-doped Si (Si:As) impurity band detector
- ⊗ Manufactured by Raytheon Vision Systems (RVS)
- ⊗ Heritage 256×256 Si:As arrays on Spitzer/IRAC
- ⊗ Spectral range 5 - 28 μm
- ⊗ 1024×1032 pixels
 - ⊗ 4 left columns, 4 right columns reference pixels
 - ⊗ 1024×1024 active pixels
 - ⊗ 25 micron pixels
- ⊗ 4 amplifiers - outputs are interleaved
 - ⊗ 1 reference output read for each 4 amp reads
 - ⊗ Full output format is 1280×1032

Detector Characteristics (cont.)


- ⊗ 2 flavors of detectors produced
 - ⊗ Baseline: thick, highly doped active layer. Requires exceptional purity. Would meet all requirements.
 - ⊗ Contingency: thinner, lower doped active region. Lower purity required. Would function as a “reasonable” detector.
- ⊗ Separate anti-reflection coatings applied
 - ⊗ Imager and SW arrays optimized for 5-10 μm (min at 6 μm)
 - ⊗ LW array optimized for 12-20 μm (min at 16 μm)
- ⊗ Well depth $\sim 250,000\text{ e}^-$ (requirement is $100,000\text{ e}^-$)
- ⊗ Temperature controlled to 1 mK
- ⊗ Readout patterns:
 - ⊗ Fastmode: $10\text{ }\mu\text{sec/pixel} = 2.76\text{ sec/frame}$
 - ⊗ Slowmode: $100\text{ }\mu\text{sec/pixel} = 27.6\text{ sec/frame}$

Reference Pixel & Output Format



Sample Image from MIRI VM1



- ⦿ Imager exposure
- ⦿ Test IMG_RAD_01 (dark exposure)
- ⦿ 300 frames in 1 integration (755 MB file!)
- ⦿ Fastmode readout
- ⦿ Contamination control cover closed, internal light sources off
- ⦿ MIRI_VM1T00000584_1_IM_S_2008-01-09T16h31m21.fits
(called MIRI_VM1_0584.fits for short)




reference outputs

Reference outputs reassembled
at top of image to improve data
compression

reference pixels



- 4 columns of reference pixels on left side (also 4 columns on right side).
- An electronics problem caused there to be 8 reference pixels on the left, but use only the 4 leftmost pixels for the homework. This has been fixed in the flight electronics.



- 4 columns of reference pixels on right side


Frame 300




Hybridization problem - detector
not properly bonded to multiplexer

Bias Subtracted, ...

Dashed lines
are reference
pixels.



Bias Subtracted, Ref. Pixels Subtracted, ...



Bias Subtracted, Ref. Pixels Subtracted, Reference Output added.

